

POWERFLEX®

PART NUMBER

PFF36-607

DESCRIPTION

DOOR STOP BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber door stop but retain the original bolts and washers to use with new PU stop.
2. Clean any dirt or corrosion around the door stop.
3. Install the new polyurethane door stop in place as shown in Figure 1. with the curved profile pointing towards the outside of the car.
4. Use the original bolts to fit the new PU stop in place, as shown in Figure 1. Tension the bolts just enough to hold the bush in place.
5. Gently shut the door to allow the bush to position itself.
6. Open the door and fully tighten the bolts.
7. Repeat on the other side and tension all hardware to manufacturers recommended torque settings.

Tip: Mark around the original bush before removal to help with positioning



Figure 1 - how to position the polyurethane bush

